


08.5000.10.830.GR

POWER: 10W LED
VOLTAGE: 220/240V 50/60Hz



Installation Instruction






1. Fix the M8*60MM expansion bolts on the ground surface (please suitable expansion bolts according to the installation environment). The wire is requested in min. 3*1 square millimeter and 0.5-0.8 meter out of ground surface.

2. Keep the power off and fix the light body on the mounting base.

3. Loose the 3pcs Allen screws on the top and remove the light head, take out the control gear bracket, connect the wires and fix back the control gear bracket into the light housing.

4. Connect to the main power for testing, if the lamp lit, the installation is correct; otherwise please carefully recheck the wires and circuit diagram accordingly, if there is nothing wrong and the lamp still can not lit, please contact with the suppliers.

DO NOT TOUCH OR CLEAN THE LED ARRAY!
IN ORDER TO AVOID DAMAGING THE LED CHIP!



Please note: 1. Please using under above voltage and make sure the product is firmly grounded
2. Product must be installed and maintained by technical staff under power off.
3. Don't use bulbs over above power rate.
4. If the external wires are out of work, please change it by technical staff for safety

LTX
LIGHTING SOLUTIONS
LTX-LED.com

Lightonix sp. z o.o.
Ul Hoza, 86 lok. 410
00-682 Warszawa, Poland
Telephone: +48 516 808 834
E-mail: info@ltx-led.com